



X-FLUSH

FOR USE IN PHOTO PROCESSING DRAIN LINES

KEEP OUT OF REACH OF CHILDREN

NET CONTENTS: 1 5 20 35 55 Gallon(s)

DYNASTY X-FLUSH



PO BOX 245013
MILWAUKEE, WI 53224
800.776.7192
www.sharecorp.com

DYNASTY X-FLUSH is non-toxic, non-pathogenic, safe, effective in sewage systems and it contains no acids or caustic materials and will not harm plumbing fixtures.

DISPOSAL:

Offer empty container for recycling. If recycling is not available, discard container in trash.

For industrial and commercial use only.

For additional information, see Safety Data Sheet.

WARNING:

This product contains, or may contain, trace quantities of a substance(s) known to the state of California to cause cancer and/or reproductive toxicity.

NFPA® Ratings

Health: 0; Flammability: 0; Reactivity: 0

INGREDIENTS/CAS#:

Water (7732-18-5); Polyoxyethylene (20) Sorbitan Monolaurate (9005-64-5); Tetrasodium ethylenediamine tetraacetate (64-02-8); Proprietary Solution (Mixture); Citric Acid (77-92-9).

DYNASTY X-FLUSH is safe for use in X-ray, CAT scan and MRI (Magnetic Resonance Imaging) drain systems.

DYNASTY X-FLUSH will digest fats, animal, vegetable and mineral oils, greases, cellulose, starches, proteins and carbohydrates into carbon dioxide and water.

DIRECTIONS:

For X-Ray drains and sinks: Add an initial treatment of 1 gallon of **DYNASTY X-FLUSH**, then 30 ounces per day for 6 weeks. After 6 weeks, **DYNASTY X-FLUSH** addition may be reduced to 20 ounces per day. Addition of **DYNASTY X-FLUSH** should be at the end of the day or during periods of lowest flow through drains.

DYNASTY X-FLUSH may be used through the "Bio-Drain Station" which dispenses product at a rate of 5 ounces per minute. Use the chart below as a guide for using **DYNASTY X-FLUSH** through the "Bio-Drain Station".

Pipe Size	Dosage	Bio-Drain Station Run Time
2 Inches	5 ounces / day	1 minute / day
4 inches	10 ounces / day	2 minutes / day
6 inches	15 ounces / day	3 minutes / day
8 inches	20 ounces / day	4 minutes / day

INGREDIENTS/CAS #:

Water (7732-18-5); Polyoxyethylene (20) Sorbitan Monolaurate (9005-64-5); Tetrasodium ethylenediamine tetraacetate (64-02-8); Proprietary Solution (Mixture); Citric Acid (77-92-9).



Please Recycle.

0532.052615