

DOUBLE D

Disinfectant - Deodorizer

Form: Aerosol Liquid

Color: Clear

Odor: Pleasant

pH: 7-8

Solubility (in water): Soluble
(in mineral spirits): No data available

VOC Content (% by weight): 85%

Flash Point (Liquid Portion): 70°F

Specific Gravity: 0.9 g/cm³

Density: 7.5 lbs/gal

Storage Stability (at 70°F): 1 year

<u>Ingredients</u>	<u>C.A.S. #</u>
Ethanol	64-17-5
Isobutane	75-28-5
Propane	74-98-6
o-Phenylphenol	90-43-7
p-tert-Amylphenol.....	80-46-6

Effective against...

- **Mycobacterium tuberculosis**
- **HIV-1 (AIDS virus)**
- **Influenza A2/Hong Kong**
- **Herpes Simplex Virus Type II**
- **Mold and Mildew**
- **Salmonella enterica**
- **Staphylococcus aureus**
- **Trichophyton mentagrophytes**

DIRECTIONS: FOR DISINFECTING HARD SURFACES as directed below, lightly depress valve (do not press valve button all the way down, do not lock) and point can to area to be sprayed.

FOR TUBERCULOCIDAL USE: Remove heavy soil and thoroughly clean surfaces prior to application of this product. Spray from 6-8" until thoroughly wet. Allow surface to remain undisturbed for at least 10 minutes at 20°C before wiping.

FOR DISINFECTING, mildew control, and deodorizing of clean surfaces: spray from 6-8" until thoroughly wet. For disinfection, allow surface to remain undisturbed for at least 10 minutes before wiping. Repeat treatment weekly to maintain effective control of mildew.

CONSULT PRODUCT LABEL FOR DETAILED INSTRUCTIONS.

HMIS®			NFPA®		
	Severe	4	Extreme		
Health	Serious	3	High	Health.....	1
Flammability.....	Moderate	2	Moderate	Flammability.....	4
Reactivity.....	Slight	1	Slight	Reactivity.....	0
Personal Protection.....	Minimal	0	Insignificant	Special Precautions	None